

Submersible Motor Pump

Amarex

Sizes DN 50 to DN 150
60 Hz
NEMA

Installation/Operating Manual



Legal information/Copyright

Installation/Operating Manual Amarex

Original operating manual

All rights reserved. The contents provided herein must neither be distributed, copied, reproduced, edited or processed for any other purpose, nor otherwise transmitted, published or made available to a third party without the manufacturer's express written consent.

Subject to technical modification without prior notice.

© KSB SE & Co. KGaA, Frankenthal 5/3/2021

Contents

	Glossary	5
1	General.....	6
1.1	Principles	6
1.2	Installation of partly completed machinery.....	6
1.3	Target group.....	6
1.4	Other applicable documents.....	6
1.5	Symbols	7
1.6	Key to safety symbols/markings.....	7
2	Safety	8
2.1	General.....	8
2.2	Intended use	8
2.3	Personnel qualification and personnel training.....	9
2.4	Consequences and risks caused by non-compliance with these operating instructions	9
2.5	Safety awareness	9
2.6	Safety information for the operator/user	9
2.7	Safety information for maintenance, inspection and installation	10
2.8	Unauthorized modes of operation.....	10
2.9	Explosion protection	10
2.9.1	Repair.....	10
3	Transport/Storage/Disposal	11
3.1	Checking the condition upon delivery	11
3.2	Transport.....	11
3.3	Storage/Preservation	11
3.4	Return to supplier.....	12
3.5	Disposal	12
4	Description of the Pump (Set)	14
4.1	General description	14
4.2	Product information as per Regulation No 1907/2006 (REACH).....	14
4.3	Designation.....	14
4.4	Name plate.....	15
4.5	Design details.....	15
4.6	Installation types	16
4.7	Configuration and function.....	18
4.8	Scope of supply.....	18
4.9	Dimensions and weights	19
5	Installation at Site	20
5.1	Safety regulations.....	20
5.2	Checks to be carried out prior to installation.....	21
5.2.1	Preparing the place of installation	21
5.2.2	Checking the lubricant level.....	21
5.2.3	Checking the direction of rotation	22
5.3	Installing the pump set	23
5.3.1	Stationary wet installation	23
5.3.2	Transportable model for wet installation	30
5.4	Electrical system.....	31
5.4.1	Information for planning the control system	31
5.4.2	Electrical connection.....	34
6	Commissioning/Start-up/Shutdown	37
6.1	Commissioning/start-up	37
6.1.1	Prerequisites for commissioning/start-up	37
6.1.2	Start-up.....	37

6.2	Operating limits.....	38
6.2.1	Frequency of starts.....	38
6.2.2	Operation on the power supply mains.....	38
6.2.3	Operation on a frequency inverter.....	39
6.2.4	Fluid handled	39
6.3	Shutdown/storage/preservation	40
6.3.1	Measures to be taken for shutdown	40
6.4	Returning to service	41
7	Servicing/Maintenance	42
7.1	Safety regulations.....	42
7.2	Maintenance/inspection.....	43
7.2.1	Inspection work.....	44
7.2.2	Lubrication and lubricant change.....	45
7.3	Drainage/cleaning	49
7.4	Dismantling the pump set.....	49
7.4.1	General information/Safety regulations.....	49
7.4.2	Preparing the pump set.....	50
7.4.3	Dismantling the pump section	50
7.4.4	Removing the mechanical seal and motor section	51
7.5	Reassembling the pump set.....	52
7.5.1	General information/Safety regulations.....	52
7.5.2	Reassembling the pump section	52
7.5.3	Reassembling the motor section.....	54
7.5.4	Leak testing.....	54
7.5.5	Checking the connection of motor/power supply	55
7.6	Tightening torques.....	55
7.7	Spare parts stock.....	55
7.7.1	Ordering spare parts.....	55
7.7.2	Recommended spare parts stock for 2 years' operation to DIN 24296	56
7.7.3	Spare parts sets	56
8	Trouble-shooting.....	57
9	Related Documents	59
9.1	General assembly drawings with list of components.....	59
9.1.1	General assembly drawing	59
9.2	Exploded views with lists of components	61
9.2.1	Exploded view	61
9.3	Wiring diagrams	64
9.3.1	Power cable AWG 15-7 or AWG 15-8	64
9.3.2	Power cable AWG 15-12 or AWG 13-12	65
9.4	Flamepaths on explosion-proof motors.....	66
9.5	Sectional drawings of the mechanical seal	69
10	Certificate of Decontamination.....	70
	Index	71

Glossary

Certificate of decontamination

If a product is to be returned to the manufacturer, the customer declares in a certificate of decontamination that the product has been properly drained to eliminate any environmental and health hazards arising from components in contact with the fluid handled.

Close-coupled design

Motor directly fitted to the pump via a flange or a drive lantern

Hydraulic system

The part of the pump in which the kinetic energy is converted into pressure energy

IE3

Efficiency class to IEC 60034-30:
3 = Premium Efficiency (IE = International Efficiency)

1 General

1.1 Principles

This operating manual is supplied as an integral part of the type series and variant indicated on the front cover (for details, please refer to the table below).

Table 1: Variants covered by this manual

Size	Impeller type	Material variant			
		G	G1	G2	GH
50-140	F	F	F	F	F
50-220	F	F	F	F	F
65-150	F	F	F	F	F
65-170	F	F	F	F	F
65-230	F	F	F	F	F
80-140	D	D	-	D	D
80-150	F	F	F	F	F
80-170	D	D	-	D	D
80-180	F, D	F, D	F	F, D	F, D
80-220	F	F	F	F	F
80-230	F, D	F, D	F	F, D	F, D
100-140	D	D	-	D	D
100-170	D	D	-	D	D
100-180	F, D	F, D	F	F, D	F, D
100-230	F, D	F, D	F	F, D	F, D
150-180	F	F	F	F	F
150-230	F, D	F, D	F	F, D	F, D

The manual describes the proper and safe use of this equipment in all phases of operation.

The name plate indicates the type series and size, the main operating data, the order number and the order item number. The order number and order item number clearly identify the pump set and serve as identification for all further business processes.

In the event of damage, immediately contact your nearest KSB service facility to maintain the right to claim under warranty.

1.2 Installation of partly completed machinery

To install partly completed machinery supplied by KSB refer to the sub-sections under Servicing/Maintenance.

1.3 Target group

This operating manual is aimed at the target group of trained and qualified specialist technical personnel. (⇒ Section 2.3, Page 9)

1.4 Other applicable documents

Table 2: Overview of other applicable documents


Document	Contents
Data sheet	Description of the technical data of the pump (set)
General arrangement drawing / outline drawing	Description of mating and installation dimensions for the pump (set), weights
Hydraulic characteristic curve	Characteristic curves showing head, flow rate, efficiency and power input

Document	Contents
General assembly drawing ¹⁾	Sectional drawing of the pump
Spare parts lists ¹⁾	Description of spare parts
Supplementary operating manual ¹⁾	E.g. for installation parts of stationary wet-installed models

For accessories and/or integrated machinery components observe the relevant manufacturer's product literature.







1.5 Symbols

Table 3: Symbols used in this manual

Symbol	Description
✓	Conditions which need to be fulfilled before proceeding with the step-by-step instructions
▷	Safety instructions
⇒	Result of an action
⇔	Cross-references
1. 2.	Step-by-step instructions
	Note Recommendations and important information on how to handle the product

1.6 Key to safety symbols/markings

Table 4: Definition of safety symbols/markings

Symbol	Description
 DANGER	DANGER This signal word indicates a high-risk hazard which, if not avoided, will result in death or serious injury.
 WARNING	WARNING This signal word indicates a medium-risk hazard which, if not avoided, could result in death or serious injury.
 CAUTION	CAUTION This signal word indicates a hazard which, if not avoided, could result in damage to the machine and its functions.
	General hazard In conjunction with one of the signal words this symbol indicates a hazard which will or could result in death or serious injury.
	Electrical hazard In conjunction with one of the signal words this symbol indicates a hazard involving electrical voltage and identifies information about protection against electrical voltage.
	Machine damage In conjunction with the signal word CAUTION this symbol indicates a hazard for the machine and its functions.

¹ If agreed upon in the scope of supply.



2 Safety

All the information contained in this section refers to hazardous situations.



In addition to the present general safety information the action-related safety information given in the other sections must be observed.

2.1 General

- This operating manual contains general installation, operating and maintenance instructions that must be observed to ensure safe operation of the system and prevent personal injury and damage to property.
- Comply with all the safety instructions given in the individual sections of this operating manual.
- The operating manual must be read and understood by the responsible specialist personnel/operators prior to installation and commissioning.
- The contents of this operating manual must be available to the specialist personnel at the site at all times.
- Information and markings attached directly to the product must always be complied with and kept in a perfectly legible condition at all times. This applies to, for example:
 - Arrow indicating the direction of rotation
 - Markings for connections
 - Name plate
- The operator is responsible for ensuring compliance with all local regulations which are not taken into account.

2.2 Intended use

- The pump set must only be operated within the operating limits described in the other applicable documents.
- Only operate pump sets which are in perfect technical condition.
- Do not operate partially assembled pump sets.
- Only use the pump set to handle the fluids described in the data sheet or product literature of the pump variant.
- Never operate the pump set without the fluid to be handled.
- Observe the limits for continuous duty specified in the data sheet or product literature (Q_{\min} and Q_{\max}) (to prevent damage such as shaft fracture, bearing failure, mechanical seal damage, etc).
- When untreated waste water is handled, the duty points in continuous operation lie within 0.7 to $1.2 \times Q_{\text{opt}}$ to minimize the risk of clogging/hardening.
- Avoid duty points for continuous operation at very low speeds and small flow rates ($< 0.7 \times Q_{\text{opt}}$).
- Observe the minimum flow rate and maximum flow rate indicated in the data sheet or product literature (to prevent overheating, mechanical seal damage, cavitation damage, bearing damage).
- Do not throttle the flow rate on the suction side of the pump set (to prevent cavitation damage).
- Consult the manufacturer about any use or mode of operation not described in the data sheet or product literature.
- Only use the respective impeller types in combination with the fluids described below.

	Free-flow impeller (impeller type F-max)	Suitable for the following fluids: Fluids containing solids and stringy material as well as fluids with entrapped air or entrapped gas
	Open two-vane impeller (impeller type D-max)	Suitable for the following fluids: Waste water containing wet wipes and long fibers

2.3 Personnel qualification and personnel training

All personnel involved must be fully qualified to transport, install, operate, maintain and inspect the machinery this manual refers to.

The responsibilities, competence and supervision of all personnel involved in transport, installation, operation, maintenance and inspection must be clearly defined by the operator.

Deficits in knowledge must be rectified by sufficiently trained specialist personnel training and instructing the personnel who will carry out the respective tasks. If required, the operator can commission the manufacturer/supplier to train the personnel.

Training on the pump (set) must always be supervised by technical specialist personnel.

2.4 Consequences and risks caused by non-compliance with these operating instructions

- Non-compliance with these operating instructions will lead to forfeiture of warranty cover and of any and all rights to claims for damages.
- Non-compliance can, for example, have the following consequences:
 - Hazards to persons due to electrical, thermal, mechanical and chemical effects and explosions
 - Failure of important product functions
 - Failure of prescribed maintenance and servicing practices
 - Hazard to the environment due to leakage of hazardous substances

2.5 Safety awareness

In addition to the safety information contained in this operating manual and the intended use, the following safety regulations shall be complied with:

- Accident prevention, health regulations and safety regulations
- Explosion protection regulations
- Safety regulations for handling hazardous substances
- Applicable standards, directives and laws

2.6 Safety information for the operator/user

- Fit protective equipment (e.g. contact guards) supplied by the operator for hot, cold or moving parts, and check that the equipment functions properly.
- Do not remove any protective equipment (e.g. contact guards) during operation.
- Provide the personnel with protective equipment and make sure it is used.
- Contain leakages (e.g. at the shaft seal) of hazardous fluids handled (e.g. explosive, toxic, hot) so as to avoid any danger to persons and the environment. Adhere to all relevant laws.
- Eliminate all electrical hazards. (In this respect refer to the applicable national safety regulations and/or regulations issued by the local energy supply companies.)
- If stopping the pump does not increase potential risk, fit an emergency-stop control device in the immediate vicinity of the pump (set) during pump set installation.

2.7 Safety information for maintenance, inspection and installation

- Modifications or alterations of the pump (set) are only permitted with the manufacturer's prior consent.
- Use only original spare parts or parts/components authorized by the manufacturer. The use of other parts/components can invalidate any liability of the manufacturer for resulting damage.
- The operator ensures that maintenance, inspection and installation is performed by authorized, qualified specialist personnel who are thoroughly familiar with the manual.
- Only carry out work on the pump (set) during standstill of the pump.
- Only perform work on the pump set when it has been disconnected from the power supply (de-energized).
- The pump (set) must have cooled down to ambient temperature.
- Pump pressure must have been released and the pump must have been drained.
- When taking the pump set out of service always adhere to the procedure described in the manual. (⇒ Section 6.3, Page 40)
- Decontaminate pumps which handle fluids posing a health hazard.
- As soon as the work has been completed, re-install and re-activate any safety-relevant devices and protective devices. Before returning the product to service, observe all instructions on commissioning. (⇒ Section 6.1, Page 37)

2.8 Unauthorized modes of operation

Never operate the pump (set) outside the limits stated in the data sheet and in this manual.

The warranty relating to the operating reliability and safety of the pump (set) supplied is only valid if the equipment is used in accordance with its intended use.

2.9 Explosion protection

Special conditions apply to the operation of explosion-proof pumps.

- The explosion-proof status of the pump set is only assured if the pump set is used in accordance with its intended use.
- The limits stated in the data sheet and on the name plate must not be exceeded under any circumstances.
- Correct monitoring of the motor temperature is imperative to ensure explosion protection.
- Observe the wiring diagrams.
- Never operate an explosion-proof pump set without temperature monitoring.
- Modifications or alteration of the pump set could affect explosion protection and are only permitted after consultation with the manufacturer.
- Only original spare parts and accessories authorized by the manufacturer must be used for explosion-proof pumps.

2.9.1 Repair


Special regulations apply to repair work on explosion-proof pumps. Modifications or alterations of the pump set can affect explosion protection and are only permitted after consultation with the manufacturer.

3 Transport/Storage/Disposal

3.1 Checking the condition upon delivery

1. On transfer of goods, check each packaging unit for damage.
2. In the event of in-transit damage, assess the exact damage, document it and notify KSB or the distributor and the insurance company about the damage in writing immediately.

3.2 Transport

	<div style="background-color: #e67e22; color: white; padding: 5px;">! DANGER</div> <p>Improper transport Danger to life from falling parts! Damage to the pump set!</p> <ul style="list-style-type: none"> ▷ Attach lifting accessories to the pump set handle only. ▷ Never suspend the pump set by its power cable. ▷ Use the lifting chain/rope included in the scope of supply exclusively for lowering or lifting the pump set into/out of the pump sump. ▷ Securely attach the lifting chain/rope to the pump and crane. ▷ Use tested, marked and approved lifting accessories only. ▷ Observe the regional transport regulations. ▷ Observe the documentation of the lifting accessory manufacturer. ▷ The load-carrying capacity of the lifting accessories must exceed the weight indicated on the name plate of the pump set to be lifted. Take into account any additional system components to be lifted.
---	---

3.3 Storage/Preservation

If commissioning is to take place some time after delivery, we recommend that the following measures be taken for pump set storage:




	<div style="background-color: #f1c40f; color: black; padding: 5px;">CAUTION</div> <p>Damage during storage due to humidity, dirt or vermin Corrosion/contamination of the pump (set)!</p> <ul style="list-style-type: none"> ▷ For outdoor storage cover the pump (set) or the packaged pump (set) and accessories with waterproof material.
	<div style="background-color: #f1c40f; color: black; padding: 5px;">CAUTION</div> <p>Wet, contaminated or damaged openings and connections Leakage or damage to the pump!</p> <ul style="list-style-type: none"> ▷ Clean and cover pump openings and connections as required prior to putting the pump into storage.

Table 5: Ambient conditions for storage

Ambient condition	Value
Relative humidity	5 % to 85 % (non-condensing)
Ambient temperature	-4 °F to 158 °F [- 20 °C to + 70 °C]

- Store the pump set under dry and vibration-free conditions, if possible in its original packaging.
- 1. Spray-coat the inside wall of the pump casing and, in particular, the impeller clearance areas with a preservative.
- 2. Spray preservative through the suction nozzle and discharge nozzle.
It is advisable to then close the pump nozzles (e.g. with plastic caps or similar).


	NOTE
	Observe the manufacturer's instructions for application/removal of the preservative.

3.4 Return to supplier


1. Drain the pump as per operating instructions. (⇒ Section 7.3, Page 49)
2. Flush and clean the pump, particularly if it has been used for handling noxious, explosive, hot or other hazardous fluids.
3. If the pump has handled fluids whose residues could lead to corrosion damage in the presence of atmospheric humidity or could ignite upon contact with oxygen, the pump must also be neutralized, and anhydrous inert gas must be blown through the pump to ensure drying.
4. Always complete and enclose a certificate of decontamination when returning the pump.
Always indicate any safety measures and decontamination measures taken.
(⇒ Section 10, Page 70)

	NOTE
	If required, a blank certificate of decontamination can be downloaded from the KSB web site at: www.ksb.com/certificate_of_decontamination

3.5 Disposal

	! WARNING
	Fluids, consumables and supplies posing a health hazard Hazard to persons and the environment! <ul style="list-style-type: none"> ▷ Collect and dispose of any preservatives, flushing liquids and fluid residues. ▷ Wear safety clothing and a protective mask, if required. ▷ Observe all legal regulations on the disposal of fluids posing a health hazard.

1. Dismantle the product.
Collect greases and other lubricants during dismantling.
2. Separate and sort the materials, e.g. by:
 - Metals
 - Plastics
 - Electronic waste
 - Greases and other lubricants
3. Dispose of materials in accordance with local regulations or in another controlled manner.



Electrical or electronic equipment marked with the adjacent symbol must not be disposed of in household waste at the end of its service life.

Contact your local waste disposal partner for returns.

If the used electrical or electronic equipment contains personal data, the operator is responsible for deleting it before the equipment is returned.

4 Description of the Pump (Set)

4.1 General description

Waste water transport, waste water management, drainage systems, waste water treatment plants, stormwater transport, recirculation, sludge treatment

4.2 Product information as per Regulation No 1907/2006 (REACH)

For information as per chemicals Regulation (EC) No. 1907/2006 (REACH), see <https://www.ksb.com/ksb-en/About-KSB/Corporate-responsibility/reach/>.

4.3 Designation

Table 6: Designation example

Position																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																	</
----------	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	----

Table 7: Designation key

Position	Code	Description
1-3	Pump type	
	ARX	Amarex
5	Impeller type	
	D-max	Open two-vane impeller
	F-max	Free-flow impeller
6-12	Size	
	100	Nominal discharge nozzle diameter [mm]
	230	Size of hydraulic system
14-16	Motor rating P _N [kW]	
	012	1,24

	084	8,40
17	Efficiency class ²⁾	
	C	IE3
	F	None
18	Number of motor poles	
	2	2 poles
	4	4 poles
19	Motor version	
	U	Non-explosion-proof, for fluid temperatures and ambient temperatures up to 104 °F [40 °C]
	Y	Explosion-proof, for fluid temperatures and ambient temperatures up to 104 °F [40 °C]
20	Motor construction type	
	S	Wet installation
21-22	Material variant	
	G	Standard variant, gray cast iron ³⁾

² IEC 60034-30 standard not binding for submersible motor pumps. Efficiencies calculated/determined according to the measurement method specified in IEC 60034-2. The marking is used for submersible motors that achieve efficiency levels similar to those of standardized motors acc. to the IEC 60034-30 standard.

³ Depending on the configuration the impeller and suction cover of versions with D-max impeller are made of nodular cast iron.

Position	Code	Description
21-22	G1	Standard variant gray cast iron, impeller made of duplex stainless steel
	G2	Standard variant gray cast iron, impeller made of white cast iron
	GH	Standard variant gray cast iron, impeller and discharge cover made of white cast iron
24-26	Nominal impeller diameter [mm]	
	090	90

	220	220
28-36	00000X100	Additional design code

4.4 Name plate




Fig. 1: Name plate (example) a) Standard pump set, b) Explosion-proof pump set

1	Designation	2	KSB order number
3	Flow rate	4	Maximum fluid and ambient temperature
5	Enclosure	6	Rated power
7	Rated speed	8	Rated voltage
9	Rated current	10	Head
11	Total weight	12	Year of construction
13	Maximum submergence	14	Thermal class of winding insulation
15	Motor number	16	Power factor at rated operating point
17	Service factor	18	Rated frequency
19	Starting current	20	Explosion protection marking

4.5 Design details

Design

- Fully floodable submersible motor pump
- Not self-priming
- Close-coupled design

Drive

- Three-phase asynchronous squirrel-cage motor in acc. with thermal class H
- Type of protection Ex db IIB (applies to explosion-proof pump sets only)
- Enclosure IP68 to EN 60529 / IEC 529

Shaft seal

- Two bi-directional mechanical seals in tandem arrangement, with liquid reservoir

Impeller type

- Various application-oriented impeller types

Bearings

Motor-end bearings:



- Grease-packed bearings sealed for life
- Maintenance-free

Pump-end bearings:

- Grease-packed bearings sealed for life
- Maintenance-free
- Reinforced bearings⁴⁾

4.6 Installation types

Table 8: Installation type S, stationary wet installation

Installation type	Description	Comment
	Guide hoop arrangement P1: pump P2: installation parts for guide hoop arrangement, installation depth = 4.9 ft / 5.9 ft / 6.9 ft P5: claw P7: chain and shackle	Only available for specific sizes, see selection configurator.
	Guide cable arrangement P1: pump P4: installation parts for guide cable arrangement, installation depth = 14.8 ft P5: claw P7: chain and shackle	

⁴ Standard for impeller type D-max, optional for impeller type F-max





Installation type	Description	Comment
	Single guide rail arrangement P1: pump P4: installation parts for single guide rail arrangement P5: claw P7: chain and shackle	Only available for specific sizes, see selection configurator.
	Twin guide rail arrangement P1: pump P4: installation parts for twin guide rail arrangement P5: claw and adapter P7: chain and shackle	Only available for specific sizes, see selection configurator.

Table 9: Installation type P, transportable wet-installed model

Installation type	Description
	P1: pump P6: pump foot P7: chain and shackle

4.7 Configuration and function



1	Shaft	2	Bearing bracket
3	Discharge cover	4	Discharge nozzle
5	Suction cover	6	Suction nozzle
7	Impeller	8	Shaft seal
9	Bearing, pump end	10	Bearing, motor end

Design The pump is designed with an axial fluid inlet and a radial outlet. The hydraulic system sits on the extended motor shaft. The shaft runs in common bearings.

Function The fluid enters the pump axially via a suction nozzle (6) and is accelerated outward in a cylindrical flow by the rotating impeller (7). In the flow passage of the pump casing the kinetic energy of the fluid is converted into pressure energy. The fluid is pumped to the discharge nozzle (4), where it leaves the pump. At the rear side of the impeller, the shaft (1) enters the hydraulic system via the discharge cover (3). The shaft passage through the cover is sealed to atmosphere with a shaft seal (8). The shaft runs in rolling element bearings (9 and 10), which are supported by a bearing bracket (2) joined to the pump casing and/or discharge cover.

Sealing The pump is sealed by two bi-directional mechanical seals in tandem arrangement. A lubricant chamber in-between the seals ensures cooling and lubrication of the mechanical seals.

4.8 Scope of supply

Depending on the model, the following items are included in the scope of supply:

Stationary wet installation (installation type S)

- Pump set complete with connection cables
- Claw with sealing elements and mounting elements
- Mounting bracket with mounting elements
- Base elbow with mounting elements
- Guiding equipment⁵⁾

⁵⁾ The guide rails are not included in the scope of supply.

Transportable model for wet installation (installation type P)

- Foot plate or pump stool with mounting elements
- Lifting rope / lifting chain⁶⁾

**NOTE**

A separate name plate is included in KSB's scope of supply.
Attach this name plate in a clearly visible position outside the place of installation,
e.g. at the control panel, pipeline or mounting bracket.











4.9 Dimensions and weights

For dimensions and weights refer to the general arrangement drawing/outline drawing or data sheet of the pump set.

⁶⁾ Optional

5 Installation at Site



5.1 Safety regulations

	<div data-bbox="507 315 683 360"> DANGER</div> <p>Improper installation in potentially explosive atmospheres Damage to the pump set!</p> <ul style="list-style-type: none"> ▸ Comply with the applicable local explosion protection regulations. ▸ Observe the information given in the data sheet and on the pump/motor name plates.
	<div data-bbox="507 593 683 638"> DANGER</div> <p>Risk of falling when working at great heights Danger to life by falling from great heights!</p> <ul style="list-style-type: none"> ▸ Do not step onto the pump (set) during installation work or dismantling work. ▸ Pay attention to safety equipment, such as railings, covers, barriers, etc. ▸ Observe the applicable local occupational safety regulations and accident prevention regulations.
	<div data-bbox="507 911 683 956"> DANGER</div> <p>Persons in the tank during pump operation Electric shock! Risk of personal injury! Danger of death from drowning!</p> <ul style="list-style-type: none"> ▸ Never start up the pump set when there are persons in the tank.
	<div data-bbox="507 1191 703 1236"> WARNING</div> <p>Hands, other body parts or foreign objects in the impeller or intake area Risk of injury! Damage to the submersible motor pump!</p> <ul style="list-style-type: none"> ▸ Never insert your hands, other body parts or foreign objects into the impeller and/or impeller intake area. ▸ Always make sure that the electrical connections are disconnected before checking that the impeller can rotate freely.
	<div data-bbox="507 1500 703 1545"> WARNING</div> <p>Impermissible solid objects (tools, screws/bolts or similar) in the pump sump/inlet tank during pump start-up Personal injury and damage to property!</p> <ul style="list-style-type: none"> ▸ Check the pump sump/inlet tank for impermissible solid objects before flooding, and remove, if necessary.

5.2 Checks to be carried out prior to installation

5.2.1 Preparing the place of installation



Place of installation for stationary models

	<div style="background-color: #f4a460; padding: 5px;"> WARNING</div> <p>Installation on mounting surfaces which are unsecured and cannot support the load</p> <p>Personal injury and damage to property!</p> <ul style="list-style-type: none"> ▷ Observe the required compressive strength class C25/30 of the concrete in exposure class XC1 as per EN 206-1. ▷ The mounting surface must have set and must be completely horizontal and even. ▷ Observe the weights indicated.
---	---

Resonances Any resonances at the usual excitation frequencies (1x and 2x rotational frequency, rotational noise) must be prevented both in the foundation and in the connected piping, as such frequencies may cause extreme vibrations.

1. Check the structural requirements.
All structural work required must have been prepared in accordance with the dimensions stated in the outline drawing/general arrangement drawing.

Place of installation for transportable models

	<div style="background-color: #f4a460; padding: 5px;"> WARNING</div> <p>Incorrect positioning / incorrect placing down</p> <p>Personal injury and damage to property!</p> <ul style="list-style-type: none"> ▷ Position the pump set vertically with the motor on top. ▷ Use appropriate means to secure the pump set against tilting and tipping over. ▷ Refer to the weights given in the data sheet / on the name plate. ▷ Adjust the handle position. (⇒ Section 5.3.1.6, Page 29)
---	--


Resonances Any resonances at the usual excitation frequencies (1x and 2x rotational frequency, rotational noise) must be prevented both in the foundation and in the connected piping, as such frequencies may cause extreme vibrations.

1. Check the structural requirements.
All structural work required must have been prepared in accordance with the dimensions stated in the outline drawing/general arrangement drawing.

5.2.2 Checking the lubricant level




The lubricant chambers have been filled with an environmentally-friendly, non-toxic lubricant at the factory.

1. Position the pump set as shown.


Fig. 2: Lubricant level

- | | |
|---|-------------------------|
| M | Optimum lubricant level |
|---|-------------------------|
2. Unscrew and remove screw plug 903.03 with joint ring 411.03.
⇒ The lubricant level must be 0.12 ft [38 mm] below the filler opening.
 3. If the lubricant level is lower, top up the lubricant chambers through the filler opening until the indicated level M is reached.
 4. Close screw plug 903.03 with joint ring 411.03. Observe the tightening torques.

5.2.3 Checking the direction of rotation

	<div style="background-color: #f4a460; padding: 5px;">! DANGER</div> <p>Pump set running dry Explosion hazard!</p> <ul style="list-style-type: none"> ▷ Check the direction or rotation of explosion-proof pump sets outside potentially explosive atmospheres.
	<div style="background-color: #f4a460; padding: 5px;">! WARNING</div> <p>Hands and/or foreign objects in the pump casing Risk of injuries, damage to the pump!</p> <ul style="list-style-type: none"> ▷ Never insert your hands or any other objects into the pump. ▷ Before connecting the pump set, check that the inside of the pump is free from any foreign objects. ▷ Never hold the pump set in your hands while checking the direction of rotation.
	<div style="background-color: #f4d03f; padding: 5px;">CAUTION</div> <p>Pump set running dry Increased vibrations! Damage to mechanical seals and bearings!</p> <ul style="list-style-type: none"> ▷ Never operate the pump set without the fluid to be handled for more than 60 seconds.

- ✓ The pump set is connected to the power supply.
1. Start the pump set and stop it again immediately to determine the motor's direction of rotation.
 2. Check the direction of rotation.
Impeller rotation must be anti-clockwise, seen from the pump mouth end. (The direction of rotation is marked by an arrow on the pump casing.)




Fig. 3: Checking the direction of rotation

3. If the impeller is running in the wrong direction of rotation, check the electrical connection of the pump set and the control system if applicable.
4. Disconnect the pump set from the power supply and make sure it cannot be switched on unintentionally.

5.3 Installing the pump set

Always refer to and comply with the general arrangement drawing/outline drawing when installing the pump set.

5.3.1 Stationary wet installation

5.3.1.1 Fastening the flanged elbow

Fastening the base elbow with chemical anchors

Depending on the pump size, the flanged elbow is fastened with chemical anchors.




Fig. 4: Fastening the flanged elbow

1. Position base elbow 72-1 at the bottom of the tank/well.
2. Fit chemical anchors 90-3.38.
3. Bolt base elbow 72-1 to the floor using chemical anchors 90-3.38.

Chemical anchor dimensions




Fig. 5: Dimensions

Table 10: Chemical anchor dimensions

Size ($d_1 \times l_1$)	d_2 ["]	t_1 ["]	t_2 ["]	$SW_1^{7)}$ ["]	$SW_2^{7)}$ ["]	M_{d1} [ft lb]
$\frac{3}{8} \times 5 \frac{1}{8}$ "	$\frac{7}{16}$	$\frac{7}{8}$	$3 \frac{9}{16}$	$\frac{11}{16}$	$\frac{1}{4}$	14,75
$\frac{5}{8} \times 7 \frac{1}{2}$ "	$\frac{11}{16}$	$1 \frac{3}{8}$	$4 \frac{15}{16}$	$\frac{15}{16}$	$\frac{7}{16}$	44,25




Size ($d_1 \times l_1$)	d_2 [mm]	t_1 [mm]	t_2 [mm]	$SW_1^{7)}$ [mm]	$SW_2^{7)}$ [mm]	M_{d1} [Nm]
M10 \times 130	12	22	90	17	6	20
M16 \times 190	18	35	125	24	12	60

Table 11: Curing times of mortar cartridge

Floor temperature		Minimum curing time	
		Dry concrete	Wet concrete
[°F]	[°C]	[min]	
$\geq +95$	$\geq +35$	10	20
$\geq +86$	$\geq +30$	10	20
$\geq +68$	$\geq +20$	20	40
$\geq +50$	$\geq +10$	60	120
$\geq +41$	$\geq +5$	60	120
$\geq +32$	≥ 0	300	600
≥ -23	≥ -5	300	600

⁷⁾ SW = Width across flats

5.3.1.2 Connecting the piping

	<div style="background-color: #f4a460; padding: 5px;">⚠ DANGER</div> <p>Impermissible loads acting on the flange of the base elbow Danger to life from leakage of hot, toxic, corrosive or flammable fluids!</p> <ul style="list-style-type: none"> ▷ Do not use the pump as an anchorage point for the piping. ▷ Anchor the pipelines in close proximity to the pump and connect them without transmitting any stresses or strains. ▷ Observe the permissible flange loads. ▷ Take appropriate measures to compensate for thermal expansion of the piping.
	<div style="background-color: #0070c0; color: white; padding: 5px;">NOTE</div> <p>When the pump set is used for draining low-level building areas, fit a swing check valve into the discharge line to avoid backflow from the sewer system.</p>
	<div style="background-color: #ffd966; padding: 5px;">CAUTION</div> <p>Critical speed of reverse rotation Increased vibrations! Damage to mechanical seals and bearings!</p> <ul style="list-style-type: none"> ▷ If long risers are used, fit a swing check valve to prevent excessive rotational speed of the pump running in reverse after it has been stopped. Watch the venting function when arranging the swing check valve. ▷ Observe the maximum permissible speed (depending on the mechanical seal and bearings) in the event of reverse rotation.




Fig. 6: Permissible flange loads

Table 12: Permissible flange loads

DN ⁸⁾	Forces								Moments							
	F _y		F _z		F _x		ΣF		M _y		M _z		M _x		ΣM	
	[lbf]	[N]	[lbf]	[N]	[lbf]	[N]	[lbf]	[N]	[lbf ft]	[Nm]	[lbf ft]	[Nm]	[lbf ft]	[Nm]	[lbf ft]	[Nm]
50	305	1350	373	1650	339	1500	588	2600	733	1000	843	1150	1027	1400	1503	2050
65	384	1700	475	2100	418	1850	746	3300	807	1100	880	1200	1100	1500	1613	2200
80	463	2050	565	2500	509	2250	893	3950	843	1150	953	1300	1173	1600	1723	2350
100	610	2700	757	3350	678	3000	1187	5250	917	1250	1063	1450	1283	1750	1907	2600
150	916	4050	1130	5000	1017	4500	1775	7850	1283	1750	1503	2050	1833	2500	2677	3650

⁸⁾ Nominal flange diameter

5.3.1.3 Fitting the guide cable arrangement

The pump set is guided into the sump or tank along two parallel, tightly stretched guide cables made of stainless steel. It attaches itself automatically to the base elbow which has been fitted to the floor.



NOTE

Should site conditions/piping layout, etc., require the cable to run off the vertical, do not exceed a maximum angle of 5° to ensure reliable fitting and guiding of the pump set.

Fitting the mounting bracket




Fig. 7: Fitting the mounting bracket

1. Fasten mounting bracket 894 to the edge of the sump opening with steel anchor bolts 90-3.37. Tighten the anchor bolts to a tightening torque of 7.4 lbf ft [10 Nm].
2. Insert clamping pieces 571 through the holes of suspension bracket 572 and fasten with nuts 920.37.
3. Fasten threaded bolt 904 with the pre-assembled clamping arrangement to the mounting bracket with nut 920.36.
Do not tighten nut 920.36 too much; allow sufficient play for subsequently tensioning the guide cable.

Inserting the guide cable




Fig. 8: Inserting the guide cable

1. Lift clamping piece 571 and insert one end of the guide cable.
2. Run cable 59-24.01 around base elbow 72-1 and back again to guide cable suspension bracket 572 and insert it into clamping piece 571.
3. Manually tension cable 59-24.01 and secure it by means of hexagon nuts 920.37.
4. Pull the cable taut by tightening hexagon nut(s) 920.36 on the upper side of the mounting bracket.

5. Secure the nuts with a second hexagon nut.
6. The loose cable ends at guide cable suspension bracket 572 can either be twisted into a ring or the end can be cut off.
After length adjustment, tape the ends to avoid fraying.
7. Attach hook 59-18.01 to mounting bracket 894 for attaching the lifting chain / lifting rope at a later stage.

Table 13: Guide cable tension

Size	Tightening torque M_A		Guide cable tension P	
	[lbf ft]	[Nm]	[lbf]	[N]
50 - ...	6.6	9	1350	6000
65 - ...	6.6	9	1350	6000
80 - ...	10.3	14	1350	6000
100 - ...	10.3	14	1350	6000
150 - ...	10.3	14	1350	6000

5.3.1.4 Fitting the guide rail arrangement

The pump set is guided into the sump or tank along one or two vertical guide rails. It attaches itself automatically to the base elbow which has been fitted to the floor.



NOTE

The guide rails are not included in KSB's scope of supply.
Select guide rail materials which are suitable for the fluid handled or as specified by the operator.

Table 14: Guide rail dimensions

Size	Outside diameter		Wall thickness ⁹⁾			
			Minimum		Maximum	
	[inch]	[mm]	[inch]	[mm]	[inch]	[mm]
DN 50	1.33	33,7	0.079	2	0.197	5
DN 65	1.33	33,7	0.079	2	0.197	5
DN 80	2.37	60,3	0.079	2	0.197	5
DN 100	2.37	60,3	0.079	2	0.197	5
DN 150	2.37	60,3	0.079	2	0.197	5

Fitting the mounting bracket





Fig. 9: Fitting the mounting bracket

1. Fasten mounting bracket 894 to the edge of the sump opening with steel anchor bolts 90-3.37. Tighten the anchor bolts to a tightening torque of 7.4 lbf ft [10 Nm].
Observe the hole pattern for the anchor bolts. (See outline drawing.)

⁹ To DIN 2440/2442/2462 or equivalent standards

Fitting the guide rails (twin guide rail arrangement)

	<div style="background-color: yellow; padding: 5px;">CAUTION</div> <p>Improper installation of the guide rails Damage to the guide rail arrangement!</p> <p>► Always adjust the guide rails so that they are in a perfectly vertical position.</p>
---	--




Fig. 10: Fitting 2 guide rails

1. Position adapter 82.5 on base elbow 72.1. Fasten it with screws 914.02, discs 550.02 and nuts 920.02.
2. Place rails 710 onto the conical bosses of adapter 82.5 and position them vertically.
3. Mark the length of rails 710 (up to the lower edge of the mounting bracket), taking into account the adjusting range of the slotted holes in mounting bracket 894.
4. Shorten rails 710 with a 90° cut to the pipe axis. Debur the rails inside and outside.
5. Insert mounting bracket 894 with clamping sleeves 81.51 into guide rails 710 until the mounting bracket rests on the rail ends.
6. Tighten nuts 920.01.
This expands the clamping sleeves so that they clamp the rails at the inside rail diameter.
7. Secure nut 920.01 with a second nut.

Fitting the guide rails (single guide rail arrangement)




Fig. 11: Fitting 1 guide rail

1. Position rail 710 (for DN 50 - DN 65) into the recess of base elbow 72.1 or (for DN 80 - DN 100) on the conical boss. Place the rail in a vertical position.
2. Mark the length of rail 710 (up to the lower edge of the mounting bracket), taking into account the adjusting range of the slotted holes in mounting bracket 894.
3. Shorten rail 710 with a 90° cut to the pipe axis. Debur the rail inside and outside.
4. Insert mounting bracket 894 into guide rail 710 until the mounting bracket rests on the rail end.

5.3.1.5 Fitting the guide hoop arrangement (for DN 50 and DN 65 only)




Fig. 12: Fitting the guide hoop arrangement

1. Insert the ends of guide hoop 571 into the recesses at base elbow 72.1.
2. Fasten the base elbow to the tank floor with two chemical anchors 90-3.38.

5.3.1.6 Preparing the pump set

Fastening the claw for twin guide rail arrangement




Fig. 13: Fastening the claw for twin guide rail arrangement

1. Fasten claw 732 with screws 914, nuts 920 and discs 550 to the discharge flange. Observe a tightening torque of 51.6 lbf ft [70 Nm].
2. Fit profile seal 410 into the opening of claw 732. This will seal the base elbow/pump connection.

Attaching the lifting chain / lifting rope

Stationary wet installation




Fig. 14: Attaching the lifting chain / lifting rope for stationary wet installation

1. Attach the lifting chain with shackle or the lifting rope to the pump set handle. This attachment point achieves a forward inclination of the pump set towards the discharge nozzle, which allows the pump claw to hook onto the base elbow.

Transportable model for wet installation





Fig. 15: Attaching the lifting chain / lifting rope for transportable wet installation

1. Unscrew screws 914.26 at the handle.
2. Reverse the handle position.
3. Fit the handle with screws 914.26, applying a thread locking agent (Loctite Type 243).

4. Tighten the screws to a tightening torque of 20 Nm with a torque wrench.
5. Attach the lifting chain with shackle or the lifting rope to the pump set handle. This attachment point achieves an upright position of the pump set.

Table 15: Types of attachment

Illustration	Type of attachment	
	Shackle with chain at the pump casing	
	59-17	Shackle
	59-18.01	Hook
	885	Lifting chain / lifting rope

5.3.1.7 Installing the pump set



NOTE

Make sure the pump set with the pre-assembled claw can easily be slipped over the mounting bracket, threaded onto the guide rails and lowered down. If required, alter the position of the crane during installation.

1. Guide the pump set over the suspension bracket / mounting bracket from above and slowly lower it down along the guide cables / guide rails. The pump set attaches itself to base elbow 72- 1.
2. Attach the lifting chain / lifting rope to hook 59-18.01 at the mounting bracket.

5.3.2 Transportable model for wet installation

Before installing the pump set, fit the three pump feet and foot plate if applicable.




Fig. 16: Attaching the lifting chain / lifting rope

Fitting the pump feet

1. Undo screws 914.03.
2. Push pump feet 182 into the openings in the suction cover.
3. Tighten screws 914.03 again to the indicated tightening torque.

Fitting the foot plate

1. Fit the foot plate to the three pump feet with bolts/screws, discs and nuts. Observe the tightening torques.

Attaching the lifting chain / lifting rope

1. Attach the lifting chain / lifting rope to the shackle on the discharge nozzle side of the pump set (see illustration and "Types of attachment" table).

Connecting the piping

The DIN connection can be connected to rigid or flexible pipes.




Fig. 17: Connection options

5.4 Electrical system

5.4.1 Information for planning the control system

For the electrical connection of the pump set observe the "Wiring diagrams" section. (⇒ Section 9.3, Page 64)



NOTE

When laying a cable between the control system and the pump set's connection point, verify that the number of cores is sufficient for the sensors. A minimum cross-section of AWG 17 [1 mm²] is required.

The motors can be connected to electrical low-voltage grids with rated voltages and voltage tolerances to IEC 60038. The permissible tolerances must be observed.

5.4.1.1 Starting method

The pump set is wired for DOL starting.

Star-delta starting is technically possible, except for pump sets with an AWG 15-8 power cable (⇒ Section 9.3, Page 64)

For reducing the starting current autotransformers or soft starters can be used. For selecting suitable devices observe the rated current of the motor. (⇒ Section 4.4, Page 15)


At least three times the rated current is required for reliable start-up. The run-up time must not exceed 4 seconds.

After start-up of the pump, a soft starter must always be bypassed.

5.4.1.2 Setting the overload protection device

1. Protect the pump set against overloading by a thermal time-lag overload protection device in accordance with IEC 60947 and local regulations.
2. Set the overload protection device to the rated current specified on the name plate.

5.4.1.3 Level control

	CAUTION
	Fluid level below the specified minimum Damage to the pump set by cavitation! ▷ Never allow the fluid level to drop below the specified minimum.

Automatic operation of the pump set in a sump or tank requires the use of level control equipment.
Observe the specified minimum fluid level.

5.4.1.4 Operation on a frequency inverter

The pump set is driven by an induction machine to IEC 60034-12 designed for fixed speed operation. In accordance with IEC 60034-25, Section 18, the pump set is suitable for operation on a frequency inverter.

Selection When selecting a frequency inverter, check the following details:

- Efficiency class at least IE2 to IEC 61800-9
- Data provided by the manufacturer
- Electrical data of the pump set, particularly the rated current
- Only voltage intermediate-circuit inverters (VSI) with pulse width modulation (PWM) and carrier frequencies between 1 and 16 kHz are suitable.

Setting Observe the following instructions for setting a frequency inverter:

- Set the current limit to max. 1.2 times the rated current. The rated current is indicated on the name plate.

Start-up Observe the following instructions for starting up a frequency inverter:

- Ensure short start ramps (maximum 5 seconds).
- Only start speed-controlled operation after 2 minutes at the earliest. Pump start-up with long start ramps and low frequency may cause clogging.




Operation Observe the following limits when operating the pump set on a frequency inverter:

- Only utilize up to 95 % of the rated power P_2 indicated on the name plate.
- Frequency range 30 to 60 Hz


Electromagnetic compatibility Operation on a frequency inverter produces interference emissions whose level varies depending on the inverter used (type, interference suppression, make). To prevent the drive system, consisting of a submersible motor and a frequency inverter, from exceeding any given limits always observe the EMC information provided by the inverter manufacturer. If the inverter manufacturer recommends a shielded power cable, make sure to use a submersible motor pump with shielded power cables.

Interference immunity The submersible motor pump generally meets interference immunity requirements. For monitoring the sensors installed the operator must ensure sufficient interference immunity by appropriately selecting and laying the power cables in the plant. No modifications are required on the power/control cable of the submersible motor pump. Suitable analyzing devices must be selected. To monitor the leakage sensor inside the motor using a special relay available from KSB is recommended.

5.4.1.5 Sensors



	<div data-bbox="507 232 683 277"> DANGER</div> <div data-bbox="494 295 1040 324">Operating an incompletely connected pump set</div> <div data-bbox="494 331 788 360">Damage to the pump set!</div> <div data-bbox="517 371 1412 430"> <ul style="list-style-type: none"> ▷ Never start up a pump set with incompletely connected power cables or non-operational monitoring devices. </div>
	<div data-bbox="507 474 639 504">CAUTION</div> <div data-bbox="494 533 729 560">Incorrect connection</div> <div data-bbox="494 566 764 595">Damage to the sensors!</div> <div data-bbox="517 607 1345 665"> <ul style="list-style-type: none"> ▷ Observe the limits stated in the following sections of this manual when connecting the sensors. </div>

The pump set features sensors that avoid hazards and damage to the pump set. Measuring transducers are required for analyzing the sensor signals supplied. Suitable devices for 230 V AC can be supplied by KSB.

	<div data-bbox="507 817 587 851">NOTE</div> <div data-bbox="494 880 1414 938">Reliable and safe operation of the pump within the scope of our warranty is only possible if the sensor signals are properly analyzed as stipulated in this manual.</div>
---	--

All sensors are located inside the pump set and are connected to the power cable. For information on wiring and core identification please refer to the wiring diagrams. The individual sensors and the limit values to be set are described in the following sections.

5.4.1.6 Motor temperature

	<div data-bbox="507 1211 683 1256"> DANGER</div> <div data-bbox="494 1274 716 1303">Insufficient cooling</div> <div data-bbox="494 1310 700 1339">Explosion hazard!</div> <div data-bbox="494 1346 702 1375">Winding damage!</div> <div data-bbox="517 1386 1355 1444"> <ul style="list-style-type: none"> ▷ Never operate a pump set without operational temperature monitoring equipment. </div>
---	--

Standard pump sets (version US):

An electric circuit with two bimetal switches serves as a temperature monitor. The bimetal switches (terminals 20 and 21, max. 250 V~ / 2 A) are connected in series and open when the winding temperature is too high.



Tripping must result in the pump set cutting out. Automatic re-starting is permitted.

Explosion-proof pump sets (version YS):

An electric circuit with two bimetal switches serves as a temperature monitor. The bimetal switches (terminals 20 and 21, max. 250 V~ / 2 A) are connected in series and open when the winding temperature is too high.

Tripping must result in the pump set cutting out. Automatic re-start is **not** permitted.

5.4.1.7 Leakage inside the motor

	<div style="background-color: #f4a460; padding: 5px; margin-bottom: 5px;">  DANGER </div> <p>Incorrect monitoring of leakage electrode</p> <p>Explosion hazard! Danger of death from electric shock!</p> <p>▷ Voltages must be < 30 V AC and tripping currents < 0.5 mA.</p>
---	---




Fig. 18: Wiring of the electrode relay: a) Connection diagram, b) Position of the electrode in the motor housing





An electrode fitted inside the motor monitors the winding space (B2) for leakage.¹⁰ The electrode is intended for connection to an electrode relay (core marking 9). Tripping of the electrode relay must result in the pump set cutting out.

Every time the relay trips the pump set, the pump set needs to be inspected and its insulation resistance measured.


The electrode relay (K1) must trip at a resistance between 3 and 60 kΩ.


Example device ▪ Télémécanique RM4-LG01

5.4.2 Electrical connection

	<div style="background-color: #f4a460; padding: 5px; margin-bottom: 5px;">  DANGER </div> <p>Electrical connection work by unqualified personnel</p> <p>Danger of death from electric shock!</p> <p>▷ Always have the electrical connections installed by a trained electrician. ▷ Observe regulations IEC 60364 and, for explosion-proof models, EN 60079.</p>
	<div style="background-color: #f4a460; padding: 5px; margin-bottom: 5px;">  WARNING </div> <p>Incorrect connection to the mains</p> <p>Damage to the mains network, short circuit!</p> <p>▷ Observe the technical specifications of the local energy supply companies.</p>



¹⁰ Optional



	CAUTION
	<p>Improper routing of power cables Damage to the power cables!</p> <ul style="list-style-type: none"> ▷ Never move the power cables at temperatures below -13 °F [-25 °C]. ▷ Never kink or crush the power cables. ▷ Never lift the pump set by the power cables. ▷ Adjust the length of the power cables to the site requirements.


	CAUTION
	<p>Motor overload Damage to the motor!</p> <ul style="list-style-type: none"> ▷ Protect the motor by a thermal time-lag overload protection device in accordance with IEC 60947 and local regulations.

For the electrical connection observe the wiring diagrams (⇒ Section 9.3, Page 64) and the information for planning the control system (⇒ Section 5.4.1, Page 31) .

The pump set is supplied with a power cable. Always connect all marked cores.

	 DANGER
	<p>Operating an incompletely connected pump set Explosion hazard! Damage to the pump set!</p> <ul style="list-style-type: none"> ▷ Never start up a pump set with incompletely connected power cables or non-operational monitoring devices.

	 DANGER
	<p>Connection of damaged power cables Danger of death from electric shock!</p> <ul style="list-style-type: none"> ▷ Check the power cables for damage before connecting them. ▷ Never connect damaged power cables. ▷ Replace damaged power cables.

	CAUTION
	<p>Flow-induced motion Damage to the power cable!</p> <ul style="list-style-type: none"> ▷ Run the power cable upwards without slack.






Fig. 19: Fastening the power cables

1. Run the power cable upwards without slack and fasten it.
2. Remove the protective caps from the power cable immediately before connection.
3. If necessary, adjust the length of the power cable to the site requirements.
4. After shortening the cable, correctly re-affix the markings on the individual cores at the cable end.



Potential equalization The pump set has not got an external PE connection (risk of corrosion).

	<div style="background-color: #e67e22; color: white; padding: 5px;"> DANGER</div> <p>Touching the pump set during operation Electric shock!</p> <p>▸ Make sure that the pump set cannot be touched during operation.</p>
---	---

6 Commissioning/Start-up/Shutdown

6.1 Commissioning/start-up




6.1.1 Prerequisites for commissioning/start-up

	 DANGER
	<p>Fluid level too low Explosion hazard! Damage to the pump set!</p> <ul style="list-style-type: none"> ▷ Completely prime the pump set with the fluid to be handled to reliably prevent the formation of a potentially explosive atmosphere. ▷ Always operate the pump set in such a way that air cannot enter the pump casing. ▷ Never allow the fluid level to drop below the specified minimum (R3). ▷ For continuous duty (S1) operate the pump set in fully submerged condition. For IE3 motors observe the minimum fluid levels R3 or R4 ▷ For intermittent periodic operation (S3, 25 %, 10 min), observe the minimum fluid levels R1 or R2.


Before commissioning/starting up the pump set, make sure that the following conditions are met:

- The pump set has been properly connected to the power supply and is equipped with all protection devices.
- The pump has been primed with the fluid to be handled. The pump has been vented.
- The direction of rotation has been checked. (⇒ Section 5.2.3, Page 22)
- The lubricants have been checked. (⇒ Section 5.2.2, Page 21)
- After prolonged shutdown of the pump (set), the activities required for returning the equipment to service have been carried out. (⇒ Section 6.4, Page 41)

6.1.2 Start-up


	 DANGER
	<p>Persons in the tank during pump operation Electric shock! Risk of personal injury! Danger of death from drowning!</p> <ul style="list-style-type: none"> ▷ Never start up the pump set when there are persons in the tank.
	CAUTION
	<p>Re-starting while motor is still running down Damage to the pump set!</p> <ul style="list-style-type: none"> ▷ Do not re-start the pump set before it has come to a standstill. ▷ Never start the pump set while the pump is running in reverse.

- ✓ The fluid level is sufficiently high.


	CAUTION
	<p>Start-up against a closed shut-off element</p> <p>Increased vibrations!</p> <p>Damage to mechanical seals and bearings!</p> <ul style="list-style-type: none"> ▷ Never start up the pump set against a closed shut-off element.

1. Fully open the discharge line shut-off element, if any.
2. Start up the pump set.

6.2 Operating limits

	! DANGER
	<p>Non-compliance with operating limits</p> <p>Damage to the pump set!</p> <ul style="list-style-type: none"> ▷ Comply with the operating data indicated in the data sheet. ▷ Never operate the pump set at ambient or fluid temperatures exceeding those specified in the data sheet or on the name plate. ▷ Never operate the pump set outside the limits specified below.

6.2.1 Frequency of starts

	CAUTION
	<p>Excessive frequency of starts</p> <p>Damage to the motor!</p> <ul style="list-style-type: none"> ▷ Never exceed the specified frequency of starts.

To prevent high temperature increases in the motor and excessive loads on the motor, sealing elements and bearings, the switching frequency shall not exceed the following number of starts per hour.

Table 16: Frequency of starts

Motor rating		Maximum frequency of starts
[kW]	[hp]	[Starts/hour]
≤ 7,5	≤ 10,0	30
> 7,5	> 10,0	10



These values apply to mains start-up (DOL, autotransformer, soft starter). This limitation does not apply to operation on a frequency inverter.

6.2.2 Operation on the power supply mains

	! DANGER
	<p>Non-compliance with permissible supply voltage tolerances</p> <p>Explosion hazard!</p> <ul style="list-style-type: none"> ▷ Never operate an explosion-proof pump (set) outside the specified range.

The maximum permissible deviation in supply voltage is $\pm 10\%$ of the rated voltage. The voltage difference between the individual phases must not exceed 1% .

6.2.3 Operation on a frequency inverter


	! DANGER
	Operation outside the permitted frequency range Explosion hazard! <p>▷ Never operate an explosion-proof pump set outside the specified range.</p>
	CAUTION
	Pumping solids-laden fluids at reduced speed Increased wear and clogging! <p>▷ Never operate the pump set with flow velocities below approx. 25 in/s [0.7 m/s] in horizontal pipes and approx. 45 in/s [1.2 m/s] in vertical pipes.</p>

Frequency inverter operation of the pump set is permitted in the frequency range from 30 to 60 Hz.

6.2.4 Fluid handled



6.2.4.1 Fluid temperature

The pump set is designed for transporting liquids. The pump set is not operational under freezing conditions.

	CAUTION
	Danger of freezing! Damage to the pump set! <p>▷ Drain the pump set or protect it against freezing.</p>

Refer to the maximum permissible fluid temperature and ambient temperature indicated on the name plate and/or in the data sheet.

6.2.4.2 Minimum level of fluid handled

	! DANGER
	Pump set running dry Explosion hazard! <p>▷ Never allow an explosion-proof pump set to run dry.</p>
	CAUTION
	Fluid level below the specified minimum Damage to the pump set by cavitation! <p>▷ Never allow the fluid level to drop below the specified minimum.</p>

The pump set is ready for operation when the fluid level has reached dimension R3, R3', R4 or R4' as a minimum (see outline drawing). R3 and R4 apply to IE3 motors (efficiency class C).





Fig. 20: Minimum fluid level

For intermittent periodic operation (S3, 25 %, 10 min), operation with the fluid level dropping down to dimension R1 or R2 (see outline drawing) is permissible. Please note that during that time frequent starting and stopping of the pump set must be avoided.

6.2.4.3 Density of the fluid handled



The power input of the pump set changes in proportion to the density of the fluid handled.


	<div style="background-color: #FFD700; padding: 5px;">CAUTION</div> <p>Impermissibly high density of fluid handled Motor overload!</p> <ul style="list-style-type: none"> ▷ Observe the information on fluid density in the data sheet. ▷ Make sure the motor has sufficient power reserves.
--	--

6.3 Shutdown/storage/preservation

6.3.1 Measures to be taken for shutdown

The pump set remains installed

	<div style="background-color: #FFA500; padding: 5px;">! WARNING</div> <p>Unintentional starting of pump set Risk of injury by moving components and shock currents!</p> <ul style="list-style-type: none"> ▷ Make sure that the pump set cannot be started up unintentionally. ▷ Always make sure the electrical connections are disconnected before carrying out work on the pump set.
	<div style="background-color: #FFA500; padding: 5px;">! WARNING</div> <p>Fluids handled, consumables and operating supplies which are hot or pose a health hazard Risk of personal injury!</p> <ul style="list-style-type: none"> ▷ Observe all relevant laws. ▷ When draining the fluid take appropriate measures to protect persons and the environment. ▷ Decontaminate pumps which handle fluids posing a health hazard.

	<p>CAUTION</p> <p>Danger of frost/freezing Damage to the pump set!</p> <p>▸ If there is any danger of frost/freezing, remove the pump set from the fluid handled and clean, preserve and store it.</p>
---	--

- ✓ Make sure sufficient fluid is available for the functional check run of the pump set.
- 1. For prolonged shutdown periods, start up the pump set regularly once every three months for approximately one minute.
This will prevent the formation of deposits within the pump and the pump intake area.

The pump (set) is removed from the pipe and stored


- ✓ All safety regulations are observed. (⇒ Section 7.1, Page 42)
- 1. Clean the pump set.
- 2. Preserve the pump set. (⇒ Section 3.3, Page 11)
- 3. Observe the information in (⇒ Section 3.3, Page 11) .


6.4 Returning to service

For returning the pump set to service, observe the items on commissioning/start-up. (⇒ Section 6.1, Page 37)

Refer to and comply with the operating limits. (⇒ Section 6.2, Page 38)

For returning the equipment to service after pump set storage also follow the instructions for maintenance/inspection.


	<p>WARNING</p> <p>Failure to re-install or re-activate protective equipment/devices Risk of personal injury from moving parts or escaping fluid!</p> <p>▸ As soon as the work is completed, re-install and/or re-activate any safety-relevant devices and protective devices.</p>
---	---






	<p>NOTE</p> <p>On pumps/pump sets older than 5 years we recommend replacing all elastomer seals.</p>
---	---

7 Servicing/Maintenance


7.1 Safety regulations

The operator ensures that all maintenance, all inspections and all installation work is performed by authorized, qualified specialist personnel who are thoroughly familiar with the manual.

	<div data-bbox="507 416 683 456"> DANGER</div> <p>Sparks produced during maintenance work Explosion hazard!</p> <ul style="list-style-type: none"> ▷ Observe the safety regulations in force at the place of installation. ▷ Never open a pump set that is connected to the power supply. ▷ Always perform maintenance work on pump sets outside potentially explosive atmospheres.
	<div data-bbox="507 728 683 768"> DANGER</div> <p>Improperly serviced pump set Explosion hazard! Damage to the pump set!</p> <ul style="list-style-type: none"> ▷ Service the pump set regularly. ▷ Prepare a maintenance schedule with special emphasis on lubricants, power cable, bearing assembly and shaft seal.
	<div data-bbox="507 1039 683 1079"> DANGER</div> <p>Electrical connection work by unqualified personnel Danger of death from electric shock!</p> <ul style="list-style-type: none"> ▷ Always have the electrical connections installed by a trained electrician. ▷ Observe the EN 61557 regulations as well as any locally applicable regulations.
	<div data-bbox="507 1292 683 1332"> DANGER</div> <p>Risk of falling when working at great heights Danger to life by falling from great heights!</p> <ul style="list-style-type: none"> ▷ Do not step onto the pump (set) during installation work or dismantling work. ▷ Pay attention to safety equipment, such as railings, covers, barriers, etc. ▷ Observe the applicable local occupational safety regulations and accident prevention regulations.
	<div data-bbox="507 1603 703 1644"> WARNING</div> <p>Unintentional starting of pump set Risk of injury by moving components and shock currents!</p> <ul style="list-style-type: none"> ▷ Make sure that the pump set cannot be started up unintentionally. ▷ Always make sure the electrical connections are disconnected before carrying out work on the pump set.

	<p>⚠ WARNING</p> <p>Hands, other body parts or foreign objects in the impeller or intake area Risk of injury! Damage to the submersible motor pump!</p> <ul style="list-style-type: none"> ▷ Never insert your hands, other body parts or foreign objects into the impeller and/or impeller intake area. ▷ Always make sure that the electrical connections are disconnected before checking that the impeller can rotate freely.
	<p>⚠ WARNING</p> <p>Fluids handled, consumables and operating supplies which are hot or pose a health hazard Risk of personal injury!</p> <ul style="list-style-type: none"> ▷ Observe all relevant laws. ▷ When draining the fluid take appropriate measures to protect persons and the environment. ▷ Decontaminate pumps which handle fluids posing a health hazard.
	<p>⚠ WARNING</p> <p>Hot surface Risk of personal injury!</p> <ul style="list-style-type: none"> ▷ Allow the pump set to cool down to ambient temperature.
	<p>⚠ WARNING</p> <p>Improper lifting/moving of heavy assemblies or components Personal injury and damage to property!</p> <ul style="list-style-type: none"> ▷ Use suitable transport devices, lifting equipment and lifting tackle to move heavy assemblies or components.
	<p>⚠ WARNING</p> <p>Insufficient stability Risk of crushing hands and feet!</p> <ul style="list-style-type: none"> ▷ During assembly/dismantling, secure the pump (set)/pump parts against tilting or tipping over.

A regular maintenance schedule will help avoid expensive repairs and contribute to trouble-free, reliable operation of the pump (set) with a minimum of maintenance expenditure and work.

	<p>NOTE</p> <p>All maintenance work, service work and installation work can be carried out by KSB Service or authorized workshops. Find your contact in the attached "Addresses" booklet or on the Internet at "www.ksb.com/contact".</p>
---	---

Never use force when dismantling and reassembling the pump set.

7.2 Maintenance/inspection

KSB recommends the following regular maintenance schedule:

Table 17: Overview of maintenance work

Maintenance interval	Maintenance work	For details see ...
Every 4000 operating hours; at least once a year	Insulation resistance measurement	(⇒ Section 7.2.1.3, Page 44)
	Checking the power cables	(⇒ Section 7.2.1.2, Page 44)
	Visual inspection of lifting chain / lifting rope	(⇒ Section 7.2.1.1, Page 44)
	Checking the sensors	(⇒ Section 7.2.1.4, Page 45)
	Changing the lubricant	
	Checking the bearings	
Every 5 years	General overhaul	

7.2.1 Inspection work



7.2.1.1 Checking the lifting chain/rope

- ✓ The pump set has been lifted out of the pump sump and cleaned. (Applies to installation type K only.)
 1. Inspect the lifting chain/rope as well as their fasteners for any visible damage.
 2. Replace any damaged components by original spare parts.

7.2.1.2 Checking the power cables

- Visual inspection**
- ✓ The pump set has been lifted out of the pump sump and cleaned.
 1. Inspect the power cables for visible damage.
 2. Replace any damaged components by original spare parts.

- Checking the ground conductor**
- ✓ The pump set has been lifted out of the pump sump and cleaned.
 1. Measure the resistance between the ground conductor and chassis ground. The electrical resistance must be lower than 1 Ω.
 2. Replace any damaged components by original spare parts.

	 DANGER
	<p>Defective ground conductor</p> <p>Electric shock!</p> <p>▷ Never switch on a pump set with a defective ground conductor.</p>

7.2.1.3 Measuring the insulation resistance

Measure the insulation resistance of the motor winding during annual maintenance work.

- ✓ The pump set has been disconnected in the control cabinet.
- ✓ Use an insulation resistance measuring device.
- ✓ The maximum measuring voltage is 500 V (maximum permissible voltage 1000 V).
 1. Measure the winding to chassis ground.
To do so, connect all winding ends together.
 2. Measure the winding temperature sensor to chassis ground.
To do so, connect all core ends of the winding temperature sensors together and connect all winding ends to chassis ground.
- ⇒ The insulation resistance of the core ends to chassis ground must not be lower than 1 MΩ.
If the resistance measured is lower, power cable and motor resistance must be measured separately. Disconnect the power cable from the motor for this purpose.

**NOTE**

If the insulation resistance of the power cable is lower than 1 MΩ, the power cable is defective and must be replaced.

**NOTE**

If the insulation resistances measured on the motor are too low, the winding insulation is defective. The pump set must not be returned to service in this case.

7.2.1.4 Checking the sensors**CAUTION****Excessive test voltage**

Damage to the sensors!

- ▷ Use a commercially available ohmmeter to measure the resistance.

The tests described below measure the resistance at the core ends of the control cable. The actual sensor function is not tested.

Bimetal switch in the motor **Table 18:** Resistance measurement of bimetal switch in the motor

Measurement between terminals ...	Resistance
	[Ω]
20 and 21	< 1

If the specified tolerances are exceeded, disconnect the connection cable at the pump set and repeat the check inside the motor.

If the tolerances are exceeded here, too, the motor part must be opened and overhauled. The temperature sensors are fitted in the stator winding and cannot be replaced.

Leakage sensor in the motor **Table 19:** Resistance measurement of the leakage sensor in the motor

Measurement between terminals ...	Resistance
	[kΩ]
9 and ground conductor (PE)	> 60

Lower resistance values would suggest water ingress into the motor. In this case the motor section must be opened and serviced.

7.2.2 Lubrication and lubricant change**7.2.2.1 Lubricating the mechanical seal**

The mechanical seal is supplied with lubricant from the lubricant chamber.

7.2.2.1.1 Intervals

Replace the lubricant every 4000 operating hours but at least once a year.

7.2.2.1.2 Lubricant quality



The lubricant chamber is filled at the factory with environmentally friendly, non-toxic lubricant of medical quality (unless otherwise specified by the customer).

The following lubricants can be used to lubricate the mechanical seals:

Table 20: Oil quality

Code	Properties	
Paraffin oil or white oil Alternative: motor oils of classes SAE 10W to SAE 20W	Kinematic viscosity at 104 °F [40 °C]	< 0.03 in ² /s [< 20 mm ² /s]
	Ignition temperature	>365 °F [>185 °C]
	Flash point (to Cleveland)	320 °F [160 °C]
	Solidification point (pour point)	5 °F [-15 °C]

- Recommended oil types:**
- Merkur WOP 40 PB, made by SASOL
 - Merkur white oil Pharma 40, made by DEA
 - Thin-bodied paraffin oil No. 7174, made by Merck
 - Thin-bodied paraffin oil, type Clarex OM, made by HAFA
 - Equivalent brands of medical quality, non-toxic
 - Water-glycol mixture

	 WARNING
	Contamination of fluid handled by lubricant Hazard to persons and the environment! ▷ Using machine oil is only permitted if the oil is disposed of properly.

7.2.2.1.3 Lubricant quantity


Table 21: Lubricant quantity depending on the motor

Motor version	Efficiency class	Number of poles	Lubricant quantity	
			[quart]	[l]
009	C	4	0.77	0.73
015	C	4	0.77	0.73
017	F	4	0.77	0.73
018	C	2	0.77	0.73
022	C	2	0.77	0.73
023	F	2	0.77	0.73
023	F	4	0.77	0.73
024	F	2	0.77	0.73
029	C	2	0.77	0.73
040	F	2	0.77	0.73
018	C	4	1.11	1.05
030	F	4	1.11	1.05
030	C	2	1.11	1.05
035	F	4	1.11	1.05
036	F	4	1.11	1.05
042	F	2	1.11	1.05
043	F	4	1.11	1.05
045	C	4	1.11	1.05
046	C	2	1.11	1.05
047	F	2	1.11	1.05
051	F	2	1.11	1.05
055	C	2	1.11	1.05
062	F	2	1.11	1.05
065	F	4	1.11	1.05
066	F	2	1.11	1.05
068	F	2	1.11	1.05

Motor version	Efficiency class	Number of poles	Lubricant quantity	
			[quart]	[l]
070	F	4	1.11	1.05
071	F	2	1.11	1.05
077	F	4	1.11	1.05
084	F	2	1.11	1.05

7.2.2.1.4 Changing the lubricant

Changing the lubricant for version YS



! WARNING

Lubricants posing a health hazard and/or hot lubricants
Hazard to persons and the environment!

- ▷ When draining the lubricant take appropriate measures to protect persons and the environment.
- ▷ Wear safety clothing and a protective mask if required.
- ▷ Collect and dispose of any lubricants.
- ▷ Observe all legal regulations on the disposal of fluids posing a health hazard.

Draining the lubricant





Fig. 21: Draining the lubricant

1. Position the pump set as shown.
2. Place a suitable container under the screw plug.



! WARNING

Excess pressure in the lubricant chamber
Liquid spurring out when the lubricant chamber is opened at operating temperature!

- ▷ Open the screw plug of the lubricant chamber very carefully.

3. Remove screw plug 903 with joint ring 411. Drain off the lubricant.



NOTE

Paraffin oil is bright and transparent in appearance. A slight discoloration, caused by the running-in process of new mechanical seals or small amounts of leakage from the fluid handled, has no detrimental effect. However, if the lubricant is severely contaminated by the fluid handled, this suggests a defect at the mechanical seals.

Filling in the lubricant




Fig. 22: Lubricant level

M	Optimum lubricant level
---	-------------------------

1. Position the pump set as shown.
2. Fill lubricant through the lubricant filler opening until the lubricant in the lubricant chamber reaches the required level M (see the following table).
3. Screw in screw plug 903 with new joint ring 411. Tighten to a torque of 17 lbf ft [23 Nm].

Table 22: Lubricant level



Motor version	Efficiency class	Number of poles	M	
			[inch]	[mm]
009	C	4	1.69	43
015	C	4	1.69	43
017	F	4	1.69	43
018	C	2	1.69	43
022	C	2	1.69	43
023	F	2	1.69	43
023	F	4	1.69	43
024	F	2	1.69	43
029	C	2	1.69	43
040	F	2	1.69	43
018	C	4	1.81	46
030	F	4	1.81	46
030	C	2	1.81	46
035	F	4	1.81	46
036	F	4	1.81	46
042	F	2	1.81	46
043	F	4	1.81	46
045	C	4	1.81	46
046	C	2	1.81	46
047	F	2	1.81	46
051	F	2	1.81	46
055	C	2	1.81	46

Motor version	Efficiency class	Number of poles	M	
			[inch]	[mm]
062	F	2	1.81	46
065	F	4	1.81	46
066	F	2	1.81	46
068	F	2	1.81	46
070	F	4	1.81	46
071	F	2	1.81	46
077	F	4	1.81	46
084	F	2	1.81	46

7.2.2.2 Lubricating the rolling element bearings

The rolling element bearings of the pump sets are grease-packed and maintenance-free.





7.3 Drainage/cleaning







	 WARNING
	Fluids handled, consumables and operating supplies which are hot or pose a health hazard Hazard to persons and the environment! <ul style="list-style-type: none"> ▷ Collect and properly dispose of the flushing fluid and of any residues of the fluid handled. ▷ Wear safety clothing and a protective mask if required. ▷ Observe all legal regulations on the disposal of fluids posing a health hazard.

1. Always flush the pump if it has been used for handling noxious, explosive, hot or other hazardous fluids.
2. Always flush and clean the pump before transporting it to the workshop. Always complete and enclose a certificate of decontamination when returning the pump set. (⇒ Section 10, Page 70)

7.4 Dismantling the pump set

7.4.1 General information/Safety regulations

	 WARNING
	Unqualified personnel performing work on the pump (set) Risk of personal injury! <ul style="list-style-type: none"> ▷ Always have repair work and maintenance work performed by specially trained, qualified personnel.
	 WARNING
	Hot surface Risk of personal injury! <ul style="list-style-type: none"> ▷ Allow the pump set to cool down to ambient temperature.

	<div data-bbox="507 190 702 235">  WARNING </div> <p>Improper lifting/moving of heavy assemblies or components Personal injury and damage to property!</p> <ul style="list-style-type: none"> ▷ Use suitable transport devices, lifting equipment and lifting tackle to move heavy assemblies or components.
	<div data-bbox="507 557 683 602">  DANGER </div> <p>Insufficient preparation of work on the pump (set) Risk of injury!</p> <ul style="list-style-type: none"> ▷ Properly shut down the pump set. ▷ Close the shut-off elements in the suction line and discharge line. ▷ Drain the pump and release the pump pressure. ▷ Shut off any auxiliary connections. ▷ Allow the pump set to cool down to ambient temperature.
	<div data-bbox="507 927 702 972">  WARNING </div> <p>Components with sharp edges Risk of cutting or shearing injuries!</p> <ul style="list-style-type: none"> ▷ Always use appropriate caution for installation and dismantling work. ▷ Wear work gloves.

Observe the safety instructions and information.

For dismantling and reassembly observe the general assembly drawing.

In the event of damage you can always contact KSB Service.

7.4.2 Preparing the pump set

- ✓ The notes and steps stated in (⇒ Section 7.4.1, Page 49) have been observed/ carried out.
- 1. Interrupt the power supply and secure the pump against unintentional start-up.
- 2. Drain the lubricant.
- 3. Drain the leakage chamber and leave it open for the duration of the disassembly.

7.4.3 Dismantling the pump section

Dismantle the pump section in accordance with the relevant general assembly drawing.

1. Remove suction cover 162.
2. Undo and remove impeller fastening screw M8.
The impeller/shaft connection is a tapered fit.
3. For dismantling of the impeller, an M10 jacking thread is provided at the impeller hub.
Screw in the forcing screw as shown in the drawing below and remove the impeller.




Fig. 23: Forcing screw



NOTE

The forcing screw is not included in the scope of supply. It can be ordered separately from KSB.

7.4.4 Removing the mechanical seal and motor section



NOTE

Special regulations apply to repair work on explosion-proof pump sets. Modifications or alteration of the pump sets can affect explosion protection and are only permitted after consultation with the manufacturer.



NOTE




The motors of explosion-proof pump sets are supplied in "flameproof enclosure" type of protection. Any work on the motor section which could affect explosion protection, such as re-winding and repair work involving machining, must be inspected by an approved expert or performed by the motor manufacturer. No modifications must be made to the internal configuration of the motor space. Repair work at the flameproof joints must only be performed in accordance with the manufacturer's instructions.

✓ The oil has been drained.

1. Slide primary ring 433.02 along the shaft.
2. Undo and remove screws 914.74.
3. Take off discharge cover 163.
4. Remove mating ring 433.02 from discharge cover 163.
5. Remove circlip 932.03.
6. Remove spring-loaded ring 433.01.
7. Remove circlip 932.08.
8. Remove the assembly consisting of bearing housing 350 and rotor 818.
9. Remove circlip 932.04.
10. Pull bearing housing 350 off the rolling element bearing.
11. Remove mating ring 433.01 from bearing housing 350.
12. Remove circlip 932.02.
13. Remove rolling element bearing 320 (reinforced version) or 321.02 (standard version).
14. Pull off rolling element bearing 321.01.

7.5 Reassembling the pump set

7.5.1 General information/Safety regulations

	<div style="background-color: #f4a460; padding: 5px;">! WARNING</div> <p>Improper lifting/moving of heavy assemblies or components Personal injury and damage to property!</p> <ul style="list-style-type: none"> ▷ Use suitable transport devices, lifting equipment and lifting tackle to move heavy assemblies or components.
	<div style="background-color: #f4d03f; padding: 5px;">CAUTION</div> <p>Improper reassembly Damage to the pump!</p> <ul style="list-style-type: none"> ▷ Reassemble the pump (set) in accordance with the general rules of sound engineering practice. ▷ Use original spare parts only.
	<div style="background-color: #2980b9; color: white; padding: 5px;">NOTE</div> <p>Before reassembling the motor section, check that all joints relevant to explosion protection (flamepaths) are undamaged. Any components with damaged flamepaths must be replaced. Refer to the flamepath positions specified in the Annex.</p>

Sequence Always reassemble the pump set in accordance with the corresponding general assembly drawing.

Sealing elements

- O-rings
 - Check O-rings for any damage and replace by new O-rings if required.
- Assembly adhesives
 - Avoid the use of assembly adhesives if possible.

Tightening torques For reassembly, tighten all screws and bolts as indicated.

7.5.2 Reassembling the pump section

7.5.2.1 Installing the mechanical seal

- Make sure the surface of the shaft is absolutely clean and undamaged.
- Immediately before installing the mechanical seal, wet the contact faces with a drop of oil.
- For easier installation of bellows-type mechanical seals, wet the inside diameter of the bellows with soapy water (not oil).
- To prevent any damage to the rubber bellows, place a thin foil of approximately 0.0039 +/- 0.0118 inch [0.1 +/- 0.3 mm] around the free shaft stub. Slide the rotating assembly over the foil into its installation position. Then remove the foil.
- ✓ The shaft and rolling element bearings have been properly fitted in the motor.
 1. Push drive-end mechanical seal 433.01 on shaft 210 and secure it with circlip 932.03.
 2. Insert O-ring 412.15 into discharge cover 163. Press the discharge cover into casing 100. Then fasten discharge cover 163 with screws 914.74.
 3. Guide the pump-end mechanical seal 433.02 onto shaft 210.

For special mechanical seals with covered spring, tighten the socket head cap screw at the rotating assembly before fitting the impeller. Observe installation dimension A.




Fig. 24: Installation dimension A

Table 23: Installation dimension A

Pump size	Installation dimension A	
	[inch]	[mm]
All sizes	1.14	29

7.5.2.2 Fitting the impeller



NOTE

For bearing brackets with tapered fit make sure that the tapered fit of impeller and shaft is undamaged and installed free from grease.




Fig. 25: Fitting the impeller, example impeller type D-max

Table 24: Minimum length of required eyebolt



Amarex	Suction nozzle DN					
	80		100		150	
	[inch]	[mm]	[inch]	[mm]	[inch]	[mm]
2 poles	2.56	65	3.54	90	-	-
4 poles	3.94	100	3.54	90	5.12	130

- Slide impeller 230 onto the shaft end and fasten it with impeller screw 914.10.
- Remove impeller screw 914.10 again.
- Screw in eyebolt M8 ¹¹⁾ instead of the impeller screw.
 - ⇒ Verify the minimum length of the eyebolt, see the corresponding table.
 - ⇒ If a different bolt length is used, insert shim(s) to establish contact with the impeller.

¹¹⁾ Not included in KSB's scope of supply

4. Tighten the eyebolt to max. 22.2 lbf ft [30 Nm].
5. Push on suction cover 162 until it rests against the impeller.
6. Suspend the pump set from the eyebolt¹¹⁾.
7. Screw in adjusting screws 904.15 until they abut against the pump casing.
8. Carefully lower down the pump set again.
9. Remove the suction cover.
10. Measure the height of screws 904.15 up to suction cover 162 and add 0.3 +/- 0.1 mm to the height of every screw.
11. Re-insert the suction cover. Fasten it with screws 914.16.
12. Suspend the pump set from the lifting equipment by the handle and rotate the impeller by hand to check that it rotates easily.
13. Undo and remove the eyebolt¹¹⁾.
14. Fit impeller screw 914.16. Tighten it to 22.2 lbf ft [30 Nm].

7.5.3 Reassembling the motor section

	<p>NOTE</p> <p>Before reassembling the motor section, check that all joints relevant to explosion protection (flamepaths) are undamaged. Any components with damaged flamepaths must be replaced. Only use original spare parts made by KSB for explosion-proof pump sets. Observe the flamepath positions specified in the Annex (Flamepaths on explosion-proof motors). Secure all screwed/bolted connections closing off the flameproof enclosure with a thread-locking agent (Loctite Type 243).</p>
	<p>! DANGER</p> <p>Wrong screws/bolts Explosion hazard!</p> <ul style="list-style-type: none"> ▸ Always use the original screws/bolts for assembling an explosion-proof pump set. ▸ Never use screws/bolts of different dimensions or of a lower property class.

7.5.4 Leak testing

After reassembly, the mechanical seal area / lubricant chamber must be checked for leakage. The leak test is performed at the lubricant filler opening.

Observe the following values for leak testing:

- **Test medium:** compressed air
- **Test pressure:** 7.25 psi maximum
- **Test duration:** 2 minutes




Fig. 26: Screwing in the testing device

1. Unscrew and remove the screw plug and joint ring of the lubricant chamber.
2. Screw the testing device tightly into the lubricant filler opening.
3. Carry out the leak test with the values specified above.
The pressure must not drop during the test period.
If the pressure does drop, check the seals and screwed connections.
Repeat the leak test.
4. If the leak test has been successful, fill in the lubricant.
(⇒ Section 7.2.2.1.4, Page 47)

7.5.5 Checking the connection of motor/power supply

Check the power cables after reassembly. (⇒ Section 7.2.1, Page 44)

7.6 Tightening torques

Table 25: Tightening torques

Thread	[lbf ft]	[Nm]
M8	12.5	17
M10	25.8	35
Impeller screw M8	22.1	30
Screw plug 903.03	17.0	23

7.7 Spare parts stock

7.7.1 Ordering spare parts

Always quote the following data when ordering replacement parts or spare parts:

- Order number
- Order item number
- Type series
- Size
- Year of construction
- Motor number

Refer to the name plate for all data.

Also supply the following data:

- Part No. and description (⇒ Section 9.1, Page 59)
- Quantity of spare parts
- Shipping address
- Mode of dispatch (freight, mail, express freight, air freight)

7.7.2 Recommended spare parts stock for 2 years' operation to DIN 24296

Table 26: Quantity of spare parts for recommended spare parts stock for 4000 operating hour or one year's continuous duty

Part No.	Description	Number of pumps (including stand-by pumps)						
		2	3	4	5	6 and 7	8 and 9	10 and more
300	Bearings (set)	1	1	2	2	2	3	30 %
433	Mechanical seals (set)	1	1	2	2	2	3	30 %
412	O-rings (set)	1	1	2	2	2	3	30 %
900	Bolts/screws (set)	1	1	2	2	2	3	30 %

Table 27: Quantity of spare parts for recommended spare parts stock for 5 years' continuous duty


Part No.	Description	Number of pumps (including stand-by pumps)						
		2	3	4	5	6 and 7	8 and 9	10 and more
230	Impeller	1	1	2	2	2	3	30 %
300	Bearings (set)	2	2	4	4	4	6	50 %
433	Mechanical seals (set)	2	2	4	4	4	6	50 %
412	O-rings (set)	2	2	4	4	4	6	50 %
834	Cable gland	1	1	2	2	2	3	30 %
900	Bolts/screws (set)	2	2	4	4	4	6	50 %

7.7.3 Spare parts sets

Table 28: Spare parts sets

Number of spare parts set		Part number	Description
99-19	900	550.23	Disc
		592	Shim
		903.03	Screw plug
		904.15	Grub screw
		914.01/.04/.10/.16/.20/.26/.74/.83	Hexagon socket head cap screw
	412	411.03	Joint ring
		412.01/.02/.07/.15/.16/.47	O-ring
	433	433.01/.02	Mechanical seal
		932.03	Circlip
	300	320, 321.01/.02	Rolling element bearing
		932.02/.04	Circlip

8 Trouble-shooting

	⚠ WARNING
	Improper remedial work Risk of personal injury! <p>► For any work performed in order to remedy faults observe the relevant information given in this operating manual and/or the product literature provided by the accessories manufacturers.</p>

If problems occur that are not described in the following table, consultation with KSB Service is required.

- A** Pump is running but does not deliver
- B** Pump delivers insufficient flow rate
- C** Excessive current/power input
- D** Insufficient discharge head
- E** Vibrations and noise during pump operation

Table 29: Trouble-shooting

A	B	C	D	E	Possible cause	Remedy
-	X	-	-	-	Pump delivers against an excessively high pressure.	Re-adjust to duty point.
-	X	-	-	-	Gate valve in the discharge line is not fully open.	Fully open the gate valve.
-	-	X	-	X	Pump running in off-design conditions (part load / overload)	Check the pump's operating data.
X	-	-	-	-	Pump and/or piping not completely vented	Vent by lifting the pump off the base elbow and lowering it again.
X	-	-	-	-	Pump intake clogged by deposits	Clean the intake, pump components and lift check valve.
-	X	-	X	X	Inlet line or impeller clogged	Remove deposits in the pump and/or piping.
-	-	X	-	X	Dirt/fibers in the clearance between the casing wall and impeller; sluggish pump rotor.	Check whether the impeller can be easily rotated. Clean the impeller if required.
-	X	X	X	X	Wear of internal parts	Replace worn parts by new ones.
X	X	-	X	-	Defective riser (pipe and sealing element)	Replace defective riser pipes. Replace sealing elements.
-	X	-	X	X	Impermissible air or gas content in the fluid handled	Contact the manufacturer.
-	-	-	-	X	System-induced vibrations	Contact the manufacturer.
-	X	X	X	X	Wrong direction of rotation	Check the electrical connection of motor and control system (if any).
-	-	X	-	-	Wrong supply voltage	Check the power cable. Check the cable connections. Check the voltage in the control cabinet.
X	-	-	-	-	Motor is not running because of lack of voltage.	Check the electrical installation. Contact the energy supplier.
X	-	X	-	-	Motor winding or power cable are defective.	Replace by new original KSB spare parts or contact the manufacturer.
-	-	-	-	X	Defective rolling element bearing	Contact the manufacturer.
-	X	-	-	-	Water level lowered too much during operation	Check level control equipment.
X	-	-	-	-	Temperature control device monitoring the winding has tripped the pump as a result of excessive winding temperatures.	The motor will restart automatically once it has cooled down (version US)

A	B	C	D	E	Possible cause	Remedy
X	-	-	-	-	Temperature limiter (explosion protection) has tripped the pump as a result of the permissible winding temperature being exceeded.	Have cause determined and eliminated by personnel trained for equipment installed in potentially explosive atmospheres.
X	-	-	-	-	Motor has been tripped by leakage monitor.	Have cause determined and eliminated by qualified and trained personnel.
-	X	-	X	-	For star-delta starting: Motor runs in star configuration only.	Check star-delta contactor.

9 Related Documents

9.1 General assembly drawings with list of components

9.1.1 General assembly drawing




Fig. 27: General assembly drawing, F-max impeller




Fig. 28: General assembly drawing, D-max impeller

Table 30: List of components

Part No.	Description	Part No.	Description
100	Casing	576	Handle
160	Cover	592	Shim
162	Suction cover	81-2.01/02	Plug
163	Discharge cover	81-55	Socket
230	Impeller	81-59	Stator
320 ¹²⁾	Rolling element bearing	818	Rotor
321.01/02 ¹³⁾	Radial ball bearing	824	Cable
330	Bearing bracket	834	Cable gland
350	Bearing housing	904.15 ¹²⁾	Grub screw
412.01/02/.15/.16/.47	O-ring	914.01/.10/.16/.26/.74/.83	Hexagon socket head cap screw
433.01/02	Mechanical seal	932.02/.03/.04/.08	Circlip
550.23	Disc	970.02	Label/plate
565	Rivet		

¹²⁾ Only used for version with impeller type D-max

¹³⁾ Only used for version with impeller type F-max

9.2 Exploded views with lists of components

9.2.1 Exploded view





Fig. 29: Exploded view, Amarex F-max

UG1800384



UG1800041

Fig. 30: Exploded view, Amarex D-max

Table 31: List of components

Part No.	Description	Part No.	Description
100	Casing	500	Ring
113	Intermediate casing	550	Disc
162	Suction cover	561	Grooved pin
182	Feet	69-6	Temperature sensor
210	Shaft	69-16	Humidity sensor
23-7	Impeller body	81-2	Plug
230	Impeller	81-59	Stator
321.01/02	Radial ball bearing	818	Rotor
330	Bearing bracket	821	Rotor core pack
355	Bearing bracket housing	834	Cable gland
410	Profile seal	99-9	Set of sealing elements

Part No.	Description	Part No.	Description
411	Joint ring	903	Screw plug
412.01/.02/.03/.04/.05	O-ring	904	Grub screw
433.01/.02	Mechanical seal	914.01/.02/.03/.04/.06	Hexagon socket head cap screw
476	Mating ring carrier	932.01/.02/.03/.04	Circlip
59-17	Shackle		

9.3 Wiring diagrams

9.3.1 Power cable AWG 15-7 or AWG 15-8





Fig. 31: Wiring diagram, motor versions US and YS, star configuration for resin-sealed cable entry

*	Shielded cable option
(A)	Motor temperature
(F)	Monitoring of leakage inside the motor (optional)
(*) Power cable with leakage sensor: AWG 15-8	

9.3.2 Power cable AWG 15-12 or AWG 13-12



UG1795620

Fig. 32: Wiring diagram, motor versions US and YS, star/delta configuration for resin-sealed cable entry

*	Shielded cable option
Ⓐ	Motor temperature
Ⓕ	Monitoring of leakage inside the motor (optional)
Power cable: AWG 15-12 or AWG 13-12	
(*) Power cable with leakage sensor	

9.4 Flamepaths on explosion-proof motors

This view applies to the following motor sizes:

18C 2 ... 29C 2

23F 2 ... 40F 2

09C 4 ... 15C 4

17F 4 ... 23F 4




Fig. 33: Overview of flamepaths

Table 32: Technical data

		Cable entry	Cover	Shaft	Pump casing
Flamepath number		1	2	3	4
Length of flamepath [mm]		≥ 12,5	≥ 12,5	≥ 12,5	≥ 12,5
Inside diameter (drilled hole) [mm]		32	174	30	120
Outside diameter (shaft) [mm]		32	174	29,9	120
Tolerance ISO inside diameter		H8	H7	-	H8
Tolerance ISO outside diameter		-	g6	-	g6
Tolerance in µm inside diameter to DIN ISO 286/2	Maximum	39	40	-	54
	Minimum	0	0	-	0
Tolerance in µm outside diameter to DIN ISO 286/2	Maximum	-	-14	-	-12
	Minimum	-	-39	-	-34
Tolerance in µm inside diameter	Maximum	-	-	20	-
	Minimum	-	-	0	-
Tolerance in µm outside diameter	Maximum	-25	-	-60	-
	Minimum	-75	-	-80	-

This view applies to the following motor sizes:

30C 2 ... 55C 2

47F 2 ... 84F 2

18C 4 ... 45C 4

35F 4 ... 77F 4




Fig. 34: Overview of flamepaths

Table 33: Technical data

		Cable entry	Cover	Shaft	Pump casing
Flamepath number		1	2	3	4
Length of flamepath [mm]		≥ 12,5	≥ 12,5	≥ 12,5	≥ 12,5
Inside diameter (drilled hole) [mm]		32	220	30	130
Outside diameter (shaft) [mm]		32	220	29,9	130
Tolerance ISO inside diameter		H8	H7	-	H8
Tolerance ISO outside diameter		-	g6	-	g6
Tolerance in µm inside diameter to DIN ISO 286/2	Maximum	39	46	-	63
	Minimum	0	0	-	0
Tolerance in µm outside diameter to DIN ISO 286/2	Maximum	-	-15	-	-14
	Minimum	-	-44	-	-39
Tolerance in µm inside diameter	Maximum	-	-	20	-
	Minimum	-	-	0	-
Tolerance in µm outside diameter	Maximum	-25	-	-60	-
	Minimum	-75	-	-80	-

This view applies to the following motor sizes:

30C 2 ... 55C 2

47F 2 ... 84F 2

18C 4 ... 45C 4

35F 4 ... 77F 4






Fig. 35: Overview of flamepaths

Table 34: Technical data

		Cable entry	Cover	Shaft	Pump casing
Flamepath number		1	2	3	4
Length of flamepath [mm]		≥ 12,5	≥ 12,5	≥ 12,5	≥ 12,5
Inside diameter (drilled hole) [mm]		52	220	30	130
Outside diameter (shaft) [mm]		52	220	29,9	130
Tolerance ISO inside diameter		H8	H7	-	H8
Tolerance ISO outside diameter		-	g6	-	g6
Tolerance in µm inside diameter to DIN ISO 286/2	Maximum	46	46	-	63
	Minimum	0	0	-	0
Tolerance in µm outside diameter to DIN ISO 286/2	Maximum	-	-15	-	-14
	Minimum	-	-44	-	-39
Tolerance in µm inside diameter	Maximum	-	-	20	-
	Minimum	-	-	0	-
Tolerance in µm outside diameter	Maximum	-25	-	-60	-
	Minimum	-75	-	-80	-

9.5 Sectional drawings of the mechanical seal

Table 35: Sectional drawings of the mechanical seal

Part No.	Code	Sectional drawing
Mechanical seal (bellows-type mechanical seal)		
433.01	Mechanical seal (bellows-type mechanical seal)	
932.03	Circlip	
433.02	Mechanical seal (bellows-type mechanical seal)	
Mechanical seal with covered springs		
433.01	Mechanical seal (bellows-type mechanical seal)	
932.03	Circlip	
433.02	Mechanical seal (mechanical seal with covered springs, HJ)	

10 Certificate of Decontamination

Type:
Order number/
Order item number¹⁴:
Delivery date:
Field of application:
Fluid handled¹⁴:

Please check where applicable¹⁴:



Corrosive



Oxidizing



Flammable



Explosive



Hazardous to health



Seriously hazardous to health



Toxic



Radioactive



Hazardous to the environment



Safe

Reason for return¹⁴:
Comments:
.....

The product/accessories have been carefully drained, cleaned and decontaminated inside and outside prior to dispatch/ placing at your disposal.

We herewith declare that this product is free from hazardous chemicals, biological and radioactive substances.

For mag-drive pumps, the inner rotor unit (impeller, casing cover, bearing ring carrier, plain bearing, inner rotor) has been removed from the pump and cleaned. In cases of leakage at the stator can, the stator space has been examined for fluid leakage; if fluid handled has penetrated the stator space, it has been removed.

For canned motor pumps, the rotor and plain bearing have been removed from the pump for cleaning. In cases of leakage at the stator can, the stator space has been examined for fluid leakage; if fluid handled has penetrated the stator space, it has been removed.

- ☐ No special safety precautions are required for further handling.
☐ The following safety precautions are required for flushing fluids, fluid residues and disposal:

.....
.....

We confirm that the above data and information are correct and complete and that shipping is effected in accordance with the relevant legal provisions.

.....
Place, date and signature

.....
Address

.....
Company stamp

¹⁴ Required field

Index

B

Bearings 16

C

Certificate of decontamination 70

Commissioning/start-up 37

D

Design 15

Direction of rotation 22

Dismantling 50

Disposal 12

Drive 15

E

Electrical connection 35

Electromagnetic compatibility 32

Event of damage 6

Ordering spare parts 55

Exploded view

Amarex D-max, version YS 62

Amarex F-max, version YS 61

Explosion protection 22, 33, 35, 38, 39, 42, 51, 54

F

Faults

Causes and remedies 57

Flamepaths 66, 67, 68

Fluid handled

Density 40

Frequency of starts 38

I

Impeller type 16

Installation

Transportable model 30

Insulation resistance measurement 44

Intended use 8

Interference immunity 32

K

Key to safety symbols/markings 7

L

Leakage monitoring 34

Level control 32

List of components 60

Lubricant 45

Intervals 44

Level 48

Quality 46

Quantity 46

M

Maintenance 43

Maintenance work 44

Mechanical seal 69

Minimum fluid level 40

O

Oil lubrication

Oil quality 46

Operating limits 8

Operation on a frequency inverter 32, 39

Order number 6

Other applicable documents 6

Overload protection 32

P

Partly completed machinery 6

Permissible flange loads 25

Piping 25

Place of installation 21

Preservation 11

Product code 14

R

Reassembly 50

Return to supplier 12

Returning to service 41

S

Safety 8

Safety awareness 9

Scope of supply 18

Sensors 33

Shaft seal 15

Shutdown 41

Spare part

Ordering spare parts 55

Spare parts sets 56

Spare parts stock 56

Start-up 37

Storage 11, 41

Supply voltage 38

T

Tightening torques 55

Types of attachment 30

W

Warnings 7

Warranty claims 6



KSB SE & Co. KGaA

Johann-Klein-Straße 9 • 67227 Frankenthal (Germany)

Tel. +49 6233 86-0

www.ksb.com